

No Bake – Pecan Coconut Praline Cookies

Ingredients

2½ cups sugar
½ cup evaporated milk
½ cup corn syrup
½ cup butter
1 teaspoon vanilla
2-2½ cups chopped pecans
2½ cups grated coconut

Directions

1. Set pecans, coconut, and vanilla off to the side
2. Mix sugar, evap milk, corn syrup, and butter in large saucepan.
3. Bring to a rolling boil & boil for 3 minutes.
4. Remove from heat & add pecans, coconut, and vanilla
5. Stir for about 4 minutes.
6. Take a spoonful of batter and place on wax paper. Let it sit until batter has hardened.
7. Remove from paper and enjoy.